



MODEL 9066 AUTOMATIC DRAIN FILTER SEPARATOR INSTALLATION AND MAINTENANCE

Bowl	Max. Pressure	Temperature range
Plastic	250 psi	40°F to 200°F
w/Auto Drain	30 psi to 175 psi	40°F to 120°F

WARNING! For compressed air service only. Do not use on life support systems or breathing air systems.

INSTALLATION

Install units so the air flow is in the direction as indicated on the head of the unit. Install filter upstream of regulators and lubricators, and as close as possible to the pneumatic tools or appliances being serviced.

OPERATION

Filtering out of dirt and foreign particles, and the separation of moisture is automatic with air flow. There are no moving parts and no adjustments are necessary.

MAINTENANCE

Internal float drain will automatically eject moisture at regular intervals. Do not permit the sediment to fill above the lower baffle. Wash filter elements at intervals with naphtha to maintain filtering efficiency. Unscrew element from head. **DO NOT USE A WRENCH.** Remove bowl and filter element by removing screw nut. Dry the filter element thoroughly before reassembling. Clean filter bowl(s) only with soapy water. Inspect O-ring, replacing if damaged or distorted. Tighten ring nut by hand, make sure O-ring is in filter head groove.

Item	Description	Kit Number	Contents
4, 5, 6	Element Kit	900565	5 Micron Sintered Bronze Element, Gaskets
1, 2, 3, 7, 8, 9, 11, 12	Rebuild Kit	900597	Bowl O-Ring, Upper Baffle, Shroud, Lower Baffle, Threaded Rod, Float Drain, Bowl, Adapter, Bowl Ring

For replacement or repair filter and regulator parts, contact EXAIR at 1-800-903-9247 or techhelp@exair.com. Call (513) 671-3322 for outside the US and Canada.

If you have any questions or problems, please contact an EXAIR Application Engineer at:

Toll Free: 1-800-903-9247 (U.S. and Canada)
 Telephone: (513) 671-3322 outside of U.S. and Canada
 Toll Free Fax: 1-866-329-3924 (U.S. and Canada)
 FAX: (513) 671-3363 outside of U.S. and Canada
 E-mail: techhelp@exair.com
 Website: www.exair.com

